

Comments

Advance	Robertson Model Number	Description	Comments	
			Mounting	Ballast Factor
ICN1P32MC	ISS132T8MVW /B	1x32T8 Instant Start HPF 120V thru 277V ballast		
ICN1S80@120 ICN1S80@230 ICN1S80@277 VZT-180	PSV180T5IV /A	1x80 Program Start HPF 100V thru 277V ballast		
ICN2S28N	PST135T5MVW /W	1x35T5 Program Start HPF 120V thru 277V ballast	*	
ICN2S28N	PSV228T5MV /A	2x28T5 Program Start HPF 120V thru 277V ballast		
ICN2S28N	PSV235T5MV /A	2x35T5 Program Start HPF 120 thru 277V ballast		
ICN2S28N	PST228T5MVW /W	2x28T5 Program Start HPF 120V thru 277V ballast		
ICN2S28N	PSW228T5120 /A	2x28T5 Program Start NPF 120V ballast	*	*
ICN2S39	PST139T5MVW /W	1x39T5 Program Start HPF 120V thru 277V ballast	*	*
ICN2S39	PSV239T5MV /A	2x39T5 Program Start HPF 120V thru 277V ballast		
ICN2S39	PSV239T5MVW /W	2x39T5 Program Start HPF 120V thru 277V ballast		
ICN2S54	PST154T5MVW /W	1x54T5 Program Start HPF 120V thru 277V ballast	*	
ICN2S54	PSR255FTMV /A	2x54T5 Program Start HPF 120V thru 277V ballast	*	
ICN2S54	PSV254T5MV /A	2x54T5 Program Start HPF 120V thru 277V ballast		
ICN2S54	PSV254T5MVEL /A	2x54T5 Program Start HPF 120V thru 277V ballast with Leads		
ICN2S54	PSV254T5MVW /W	2x54T5 Program Start HPF 120V thru 277V ballast		
ICN-3P32SC	ISL332T8MVW /B	3x32T8 Instant Start HPF 120V thru 277V ballast		
ICN45490C2LSG	PSY454T5MVEL /A	4x54T5 Program Start HPF 120V thru 277V ballast with Leads	*	
ICN-4P32SC REL4P32SC VEL4P32SC	ISL432T8MVW /B	4x32T8 Instant Start HPF 120V thru 277V ballast		
IEZ2S24D	PST224T5MVW /W	2x24T5 Program Start HPF 120V thru 277V ballast	*	
IOP1S32SC	PSA132T8HEMV /A	1x32T8 Program Start HPF, 120V thru 277V NEMA Premium ballast		
IOP1S32SC	PSA132T8HEMV /A	1x32T8 Program Start HPF 120V thru 277V NEMA Premium ballast		
IOP-259-SC	ISR259T8MVW /B	2x96T8 Instant Start HPF 120V thru 277V ballast		
IOP2P32SC ICN2P32SC VEL2P32-SC	ISS232T8MVW /B	2x32T8 Instant Start HPF 120V thru 277V ballast		
IOP2S32SC	PSA232T8HEMV /A	2x32T8 Program Start HPF 120V thru 277V NEMA Premium ballast		
IOPA1P32LWSC	ISL132T8HEMVL /A	1x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA2P32LWSC	ISL232T8HEMVL /A	2x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA2P32LWSC	ISL232T8HEMVL /A	2x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA2P32SC	ISL232T8HEMV /A	2x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA2P32SC	ISL232T8HEMV /A	2x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA3P32LWSC	ISL332T8HEMVL /A	3x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA3P32LWSC	ISL332T8HEMVL /A	3x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA3P32SC	ISL332T8HEMV /A	3x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA3P32SC	ISL332T8HEMV /A	3x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA3P32SC	ISL432T8HEMV /A	4x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA4P32LWSC	ISL432T8HEMVL /A	4x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA4P32LWSC	ISL432T8HEMVL /A	4x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
IOPA4P32SC	ISL432T8HEMV /A	4x32T8 Instant Start HPF 120V thru 277V NEMA Premium ballast		
R2E75STP ICN2P60SC	ISD296T12MV /B	2x96T12 Instant Start HPF 120V thru 277V ballast		
R2E75STP ICN2P60SC	ISL260T12MV /B	2x60T12 Instant Start HPF 120V thru 277V ballast		

Comments

Advance	Robertson Model Number	Description	Comments	
			Mounting	Ballast Factor
R2E75STP ICN2P60SC	IED296T12120 /B	2x96T12 Instant Start HPF 120V ballast	*	
R2E75STP ICN2P60SC	IEL260T12120 /B	2x60T12 Instant Start HPF 120V ballast		
RCN2S32SC IOP2S32SC	PSA232T8HEMV /A	2x32T8 Program Start HPF, 120V thru 277V NEMA Premium ballast		
REB2P32N	ISL232T8120 /B	2x32T8 Instant Start NPF 120V ballast		
REB2P32SC	ISU232T8120 /B	2x32T8 Instant Start NPF 120V ballast		
REB2P32SC	IEA232T8120N /B	2x32T8 Instant Start NPF 120V ballast		
REB4P32N	ISL432T8120 /B	4x32T8 Instant Start NPF 120V ballast		
REL1S40SC	RSW140T12120 /A	1x40T12 Preheat-RapidStart NPF 120V ballast	*	
REL2P32SC	IES232T8120 /B	2x32T8 Instant Start HPF 120V ballast		
REL2S110	RSD296T12HOMV	2x96T12 Rapid Start 120V thru 277V ballast	*	*
REL2S40SC	RSW240T12120 /B	2x40T12 Preheat-RapidStart NPF 120V ballast	*	*
REL2S40SC R2S40TP	RES240T12120 /B	2x40T12 Rapid Start HPF 120V ballast		
REL3P32SC	IEL332T8120 /B	3x32T8 Instant Start HPF 120V ballast		
REL4P32SC	IEL432T8120 /B	4x32T8 Instant Start HPF 120V ballast		
REZ-232-SC	PSL232T8MV3D /A	2x32T8 Program Start HPF 120V thru 277V Dimming ballast		