Understanding the Robertson Electronic Ballast Model Numbering System

Example Model No.

PSM 226 CQ MV DW

1 2 3 4 5 6 7 8

1) Circuit Type	2) Case Material	3) Case Style	4) Lamp Qty	5) Lamp Watts	6) Lamp Type	7) Voltage	8) Features
P=Program	A=Aluminum	M=(28)			CQ=Compact Quad	MV=Multi-Voltage	B=Bottom Entry
	P=Plastic	P=(24)			CS=Compact Special	347V	BS=Bottom Entry/Studs
	S=Steel	T=(19)			CT=Compact Twin		BL=Bottom Leads
		V=(23)			M=Compact Multi		BLS=Bottom Leads/Studs
					T=Linear		DW=Dual Entry
					TR=Compact Triple		DWS Dual Entry/Studs
					TT=Long Twin		T=Top Entry
							W=White